

# V12 NcEditor Laser Cutting Control System Bus Type Commissioning Guide

Version: 2018.9 1st Version

Author: Document Department

Weihong Corporation, All Rights Reserved

1	Checking Configuration and Wiring.....	1
1.1	Checking Production Configuration.....	1
1.2	Checking Production Wiring.....	2
2	Setting Driver Parameters .....	3
2.1	Setting Driver Parameters in NcEditor.....	3
2.2	Setting Station Address.....	4
2.2.1	Setting Station Address of YASKAWA Driver .....	4
2.2.2	Setting Station Address Value of WISE Driver .....	5
3	Setting System Parameters in NcEditor.....	6
4	Commissioning Driver.....	7
4.1	Before Commissioning.....	7
4.2	How to Commission Driver .....	8
5	Setting Machine Origin .....	13
6	List of Parameters .....	14
6.1	Basic Driver Parameters .....	14
6.2	Basic System Parameters.....	15


## 1 Checking Configuration and Wiring

### 1.1 Checking Production Configuration

To confirm the hardware setting is complete and correct, please refer to the following list:


- Lambda 5M controller
- PM95A servo control card
- YASKAWA driver or WISE driver of M2 fieldbus type (with terminating resistor)
- EX33A terminal board (for extension)

To confirm V12 NcEditor has been set to bus type, please refer to the following path in the menu bar:



## 1.2 Checking Production Wiring

Take WISE driver of M2 communication instruction type as an example. To check the wiring, please refer to the following wiring diagram.



## 2 Setting Driver Parameters

For different types of drivers, parameters and setting methods vary from type to type.

This chapter mainly focuses on how to set the basic parameters and station address values of YASKAWA  $\Sigma 5/\Sigma 7$  driver and WISE driver.

To set parameters, do one of the following:

- Set parameters on the front panel of the driver.

Please refer to user manual or instruction of the driver for details.


- Set parameters in V12 NcEditor.

Please refer to [Setting Driver Parameters in NcEditor](#).

### 2.1 Setting Driver Parameters in NcEditor

To set parameters in V12 NcEditor, do the following:

1. In the menu bar, click **System** → **Driver Parameters Setting**. **Driver Parameter** dialog box pops up:



2. Click **Refresh** to get the latest parameters.

3. Double click target parameter to set.

To get more information about the basic parameters that you need to set here, please refer to [List of Parameters](#) for details.

## 2.2 Setting Station Address

Setting right station address is the key to data transmission among NcEditor, Lambda controller and the driver.

The corresponding station address value of each axis is unique. It should be consistent with station address set value of the driver in V12 NcEditor system. If the value is set to 0, the communication function is disabled.

### 2.2.1 Setting Station Address of YASKAWA Driver


For a YASKAWA driver, to set station address value, do the following:

1. To enable bus function, set No. 1 ~ No.4 toggle switches to ON, ON, OFF, OFF in order.
2. To set station address No., rotate rotary switch to any number from 1 to 9.
3. It is suggested to set station address No. in order (e.g. X-axis: 1; Y-axis: 2; Z-axis: 3, etc.).
4. In V12 NcEditor, set driver station address value of current axis to station address No. that corresponds to the rotary switch.

## 2.2.2 Setting Station Address Value of WISE Driver

For a WISE driver, to set station address value, do the following:

1. Set parameter **Pr001 Control Mode Setup** to **1**.
2. Set station address No. as following:




3. Restart the driver.
4. In V12 NcEditor, set driver station address value of current axis to station address No. that corresponds to the panel.

### 3 Setting System Parameters in NcEditor

To set system parameters in V12 NcEditor, do the following:

1. In the menu bar, click **System** → **System Parameters. Parameter Setting** dialog box pops up:



The screenshot shows the 'Parameter Setting' dialog box. On the left, there are buttons for 'AllParam', 'OperateParam', 'AxisParam', 'ProgramParam', and 'OtherParam'. Below these is a 'Permission' section with checkboxes for 'Operator' (checked) and 'Manufacturer' (unchecked), and a 'Set Password' button. The main area is a table with columns: No., Name, Value, Unit, Effect Time, and Parameter description. The table is categorized by sections: 1.0 Manu, 1.1 FixedPoint, 1.2 Bkref, 2.0 XAxisParam, 2.1 YAxisParam, and 2.2 ZAxisParam. The table lists parameters N01 through N11 with their respective values and descriptions.

No.	Name	Value	Unit	Effect Time	Parameter description
<b>1.0 Manu</b>					
N01	Rapid jogging speed	18000.000	mm/min	Immediately	The speed under Rapid-Jog mode
N02	Jogging speed	6000.000	mm/min	Immediately	The default speed under Jog mode
N03	Stepping speed	6000.000	mm/min	Immediately	The default speed under Stepping mode
<b>1.1 FixedPoint</b>					
N04	X machine coordinate	0.000	mm	Immediately	X machine coordinate of the fixed point
N05	Y machine coordinate	0.000	mm	Immediately	Y machine coordinate of the fixed point
<b>1.2 Bkref</b>					
N06	Force homing before...	NO		Immediately	Force homing before machining
<b>2.0 XAxisParam</b>					
N07	X Axis Starting speed	0.000	mm/min	Immediately	Starting speed; range: [0, Max]
N08	X Axis G00 Speed	6000.000	mm/min	Immediately	It is the default speed of axis X
<b>2.1 YAxisParam</b>					
N09	Starting speed	0.000	mm/min	Immediately	Starting speed; range: [0, Max]
N10	Y Axis G00 Speed	6000.000	mm/min	Immediately	It is the default speed of axis Y
<b>2.2 ZAxisParam</b>					
N11	Z Axis Starting speed	0.000	mm/min	Immediately	Starting speed; range: [0, Max]

2. Check **Manufacturer** to enable manufacturer's right.
3. Double click target parameter to set.

To get more information about the basic parameters that you need to set here, please refer to [List of Parameters](#) for details.

## 4 Commissioning Driver

According to current machine state, the driver automatically adjusts servo gain of servo unit and optimizes response.

### 4.1 Before Commissioning

Before commissioning, ensure the following:

- To YASKAWA driver
  - Main circuit power is ON.
  - There is no overtravel.
  - There is no alarm and warning information.
  - Gain selection switch must be manual: Pn139=n.□ □ □ 0.
  - No motor test function selection must be invalid: Pn00C=n.□ □ □ 0.
  - HWBB function must be invalid.
  - Cannot set parameter writing inhibit setup to “Prohibit writing”: Fn010=n.□ □ □ 0.
  - Free adjustment function must be invalid: Pn170=n.□ □ □ 0.
- To WISE driver
  - Main circuit power is ON.
  - There is no overtravel.
  - There is no alarm and warning information.
  - Station address setting of driver is consistent with that of software.



## 4.2 How to Commission Driver

To commission driver in V12 NcEditor, do the following:

1. In the menu bar, click **System** → **Driver Adjust**. **Driver Commissioning** dialog box pops up.

1 Set Axis and Range > 2 Set Function > 3 Inertia Estimation > 4 Rigidity Setting > Finish

Adjust Axis: X

Machine Coord: 29.320 + -

1st Limit: 29.320 Set

2nd Limit: 29.320 Set

Steps:


1. Select the axis;
2. Manually move the axis to safe position, and set 1st Limit;
3. Move the axis to the second safe position, and set 2nd Limit.

Tip: Distance between the first limit and the second limit should be within range[15, 500].

Next

## 2. Set axis and range.

For detailed steps, refer to the following picture. Click **Next** after setting.



1 Set Axis and Range 2 Set Function 3 Inertia Estimation 4 Rigidity Setting Finish

Adjust Axis: X

Machine Coord: 29.320 + -

1st Limit: 29.320 Set

2nd Limit: 29.320 Set

Steps:  
1. Select the axis;  
2. Manually move the axis to safe position, and set 1st Limit;  
3. Move the axis to the second safe position, and set 2nd Limit.

Tip: Distance between the first limit and the second limit should be within range[15, 500].

Next

### 3. Set function.

Select proper **Initial Mode** and **Initial Rigidity**. Click **Next** after setting.

1 Set Axis and Range > 2 Set Function > 3 Inertia Estimation > 4 Rigidity Setting > Finish

Adjust Axis: X

1st Limit: 57.517

2nd Limit: -67.783

Initial Mode: Positioning

Initial Rigidity: Standard(Ball screw)

Back Next

## 4. Estimate inertia.

Click **Start**. The system automatically generates the following parameters. Click **Next** after estimation.

1 Set Axis and Range 2 Set Function 3 Inertia Estimation 4 Rigidity Setting Finish

Adjust Axis: X

1st Limit: 57.517

2nd Limit: -67.783

Initial Mode: Positioning

Initial Rigidity: Standard(Ball screw)

Inertia Ratio: 8


Variable Load: 0.0

Friction: 3.8

Start Stop Back Next

5. Set rigidity.

Select proper **Mode** and **Filter Mode**. Then click **Start**. The system automatically generates the following parameters.



The screenshot shows the '4 Rigidity Setting' window with the following parameters:

Parameter	Value
Mode	Positioning
Filter Mode	1 valid
Rigidity Value	13
Resonant Frequency	0
1st Position Loop Gain	480
1st Velocity Loop Gain	270
1st Velocity Loop Time Constant	210
1st Torque Filter	84
Velocity Feed Forward Gain	300
Velocity Feed Forward Filter	200
3rd Notch Frequency	5000
3rd Notch Width Selection	2
3rd Notch Depth Selection	0
4th Notch Frequency	5000
4th Notch Width Selection	2
4th Notch Depth Selection	0


Buttons at the bottom: Start, Stop, Refresh, Back, Save.

6. Click **Save**. Driver commissioning completes.

## 5 Setting Machine Origin

For different types of motors, setting machine origin methods vary from type to type:

- For absolute motor:
  - To set machine origin by setting absolute value manually, do the following:
    1. In the menu bar, click **System** → **Absolute Setting**. **Absolute Value** dialog box pops up:



2. Check **Setting Enabled**.
  3. Decide machine origin position by right-hand coordinate system rule. Then move cutting head to the machine origin.
  4. Click **Set** to set coordinates of X-axis, Y-axis and Y2-axis.
- If the imported datum was set before. Click **Import Datum** in **Absolute Value** dialog box to set coordinates directly.
  - For non-absolute motor:

There is no need to set absolute value. Laser head returns to machine origin normally.

## 6 List of Parameters

This chapters mainly introduces basic driver and system parameters.

### 6.1 Basic Driver Parameters

See tables below for the basic driver parameters that you need to set properly. To get more information about other parameters, please refer to user manual or instruction of the driver.

Table of basic parameters of YASKAWA driver:

No.	Name	Set value
Pn00B	Basic switch B of function selection	0000 (three phase)/0100 (single phase)
Pn50A	Input signal selection 1	8881
Pn50B	Input signal selection 2	8888
Pn50E	Input signal selection 1	0000
Pn50F	Input signal selection 2	0100
Pn510	Input signal selection 3	0000
Pn514	Input signal selection 4	0000

Table of basic parameters of WISE driver:

No.	Name	Set value
Pr001	Control mode setup	1 (position control mode)

## 6.2 Basic System Parameters

In V12 NcEditor, basic parameters that you need to set are the following:

### **Driver station address (X/Y1/Y2)**

It should be consistent with rotary switch setting of driver station address. 0 represents invalid address.

### **Enable absolute value**

Select whether to enable absolute value.

If absolute value is enabled, the driver needs to connect to an absolute-type motor.

### **Driver station address set switch (X/Y1/Y2)**

The value should be consistent with the driver station address rotary switch set value.

### **Encoder digit (X/Y1/Y2)**

It refers to the digit number of encoder of the servo motor.

### **Numerator of electronic gear ratio (X/Y1/Y2)**

It should be consistent with electronic gear ratio (numerator) of the driver.

### **Denominator of electronic gear ratio (X/Y1/Y2)**

It should be consistent with electronic gear ratio (denominator) of the driver.

### **Motor rotation mode (X/Y1/Y2)**

It should be consistent with motor rotation mode of the driver.

### **Axis encoder direction (X/Y1/Y2)**

It should be consistent with axis encoder direction of the driver.



专业·专心·专注

SPECIALIZED/CONCENTRATED/FOCUSED



上海维宏电子科技股份有限公司

地址：上海市奉贤区沪杭公路1590号

邮编：201401 咨询热线：400 882 9188

邮箱：weihong@weihong.com.cn

网址：www.weihong.com.cn